



## Wireless Measurement Read WiMER2 User Guide

### ⚠ Important Notes

- Turn off the device after use. It will **NOT** turn off automatically.
- Do **NOT** open the device. Opening causes permanent damage and voids the warranty.

### Description

- ① **On/Off Switch** – slides to turn WiMER2 on/off
- ② **Micro USB** – connects to charging cable to recharge the battery
- ③ **RS232 Connector** – connects to the gage through a data cable
- ④ **On/Off LED** – turns green when WiMER2 is on
- ⑤ **CHG LED** – turns on red when the device is in charging. It changes to green when the battery is fully charged



### Included in the box

- WiMER2 Base 1X
- USB Charging Cable 1X
- USB Power Adapter 1X
- User Guide 1X

### Compatible Software

- iOS: DialRead, DialReadPad, MultiGage Reader
- Android: Dial Reading
- Windows: Dial Reading (BLE Dongle Required)
- iOS App can be directly downloaded from the App Store for FREE.
- Android and Windows programs are available on Motionics website.

### Quick Start

- Turn on WiMER2 and connect to Fowler Test Indicator.
- Run one of the aforementioned Apps/software.
- In the main page, tap Pair button to bring up a new pairing page.
- Plug in USB Bluetooth dongle if using Windows PC.
- Wait for the software to finish scanning nearby devices, select **WiMERXXX** to connect.
- Connection may take a few seconds, once paired, instrument reading shows in the software.