



Wireless Measurement Read WiMER4D User Guide

⚠ Important Notes

- Detach the device from the protractor after use.
- Do **NOT** open the device. Opening causes permanent damage and voids the warranty.

Description

- ① **10-Pin Connector** – connects to Mitutoyo 950-318/PRO3600 protractor
- ② **Blue LED** – turns on when device is connected to protractor



Included in the box

- WiMER4D 1X
- User Guide 1X

Compatible Software

- iOS: MultiGage Reader
- Android: MultiGage Reader
- Windows: MultiGage Reader (BLE Dongle Required)
- iOS app can be directly downloaded from the App Store for FREE.
- Android app can be directly downloaded from the Google Play Store for FREE.
- Windows software is available on Motionics website.

Quick Start

- Attach WiMER4D to the Mitutoyo 950-318/PRO3600 protractor, turn on protractor.
- Plug in USB Bluetooth dongle if using Windows PC.
- Run one of the aforementioned apps/software.
- In the main page, tap Scan/+ button to bring up a new pairing page.
- Wait for the software to finish scanning nearby devices, select **WiMERXXXX** to connect.
- Connection may take a few seconds, once paired, instrument reading shows in the software.