



**! IMPORTANT NOTES**

- Do **NOT** remove the T-handle or the bottom magnet from the device.
- The device has no on/off switch and operates constantly in a low energy mode. Disconnect the device from the app after use to save battery. Device connection is controlled from the ShakerWatch app.

**📦 PRODUCT DESCRIPTION**

- 1 **Top Cover:** Open to replace CR2477 coin battery. Do not over tighten the screws.
- 2 **Magnetic Base:** Do **NOT** remove. Clean before putting on any machine.
- 3 **T-Handle:** Handle to remove the device from a machine.
- 4 **Side Mounting Hole:** 1/4-28 thread for calibration mounting.
- 5 **CR2477 Coin Battery x2**



**↓ SOFTWARE DOWNLOAD**

ShakerWatch app is a paid app for iPad devices but is already included in the kit purchase.

For direct download, click the link below or scan the QR code.

ShakerWatch iPad App  
<https://apps.apple.com/us/app/shakerwatch/id6443781151>

[ShakerWatch App](#)



**APP INSTALLATION**

- Check your email for installation License Code
- Open the App Store on your iPad and go to the Apps section by hitting Apps at the bottom of the screen
- Scroll down to the bottom of the page and tap Redeem. If a window pops up showing Sign into iTunes Store, enter your Apple ID and password and hit OK.
- Tap Enter Code Manually, enter license code and tap Redeem. The app will start to download automatically.

**📋 QUICK START**

- Open the top cover to install or replace the CR2477 coin battery if the battery is not already installed.
- Run ShakerWatch app and tap START button on the home page.
- Add or select a plant - machine - test and tap Open to enter test summary page.
- Tap gear icon on top right corner to configure settings for the test.
- Open Test Information to enter test info or select any of the available tests to collect test data.
- From any page with the sensor icon, tap the sensor icon to open sensor page. It will automatically scan for a nearby ShakerWatch accelerometer and connect. Tap the Disconnect button to disconnect.
- From any page with Notes/Photos button, tap the button to add notes/photos for the test.
- From any page with View PDF button, tap the button to view and export test report.
- Once the test is complete, tap Lock Test to sign off and convert the test to read only.